

Description of the Instruction Set

Venus

as implemented in the
TANGO Controller



In der Murch 15
35579 Wetzlar
Germany
Tel.: +49/6441/9116-0
www.marzhauser.com

1. Table of Contents

1. Table of Contents	2
2. Introduction	8
3. Instruction and Response Syntax Description	9
3.1. mode	10
3.2. parameter	10
4. Stack Instructions.....	11
4.1. gsp.....	11
4.2. pop	11
4.3. clear.....	11
4.4. nclear.....	11
5. Venus-1 vs. Venus-2 Instructions Cross Reference.....	12
6. Communication Interface Settings	13
6.1. getbaud.....	13
6.2. setbaud.....	13
6.3. getcts.....	13
6.4. setcts	14
7. Controller Informations.....	15
7.1. version.....	15
7.2. nversion.....	15
7.3. identify	15
7.4. nidentify	15
7.5. getserialno	15
7.6. getstageno.....	15
7.7. tango	16
8. System Configuration.....	17
8.1. save	17
8.2. restore	17
8.3. reset	17
8.4. getpowerup.....	18
8.5. setpowerup.....	18
8.6. getipreter	19
8.7. setipreter.....	19
9. Motor Configuration	20
9.1. gi.....	20
9.2. si.....	20
9.3. getpolepairs	20



9.4.	setpolepairs	20
9.5.	getmotiondir	21
9.6.	setmotiondir	21
10.	Controller States and Error Messages	22
10.1.	geterror (ge)	22
10.2.	getnerror (gne)	22
10.3.	status (st)	22
10.4.	nstatus (nst)	23
11.	General Adjustments	24
11.1.	getunit	24
11.2.	setunit	24
11.3.	getusteps	25
11.4.	setusteps	25
11.5.	getdim	25
11.6.	setdim	25
11.7.	getpdisplay	26
11.8.	setpdisplay	26
11.9.	getpitch	26
11.10.	setpitch	26
11.11.	getaccel (ga)	27
11.12.	setaccel (sa)	27
11.13.	getnaccel (gna)	27
11.14.	setnaccel (sna)	27
11.15.	getnaccelfunc	28
11.16.	setnaccelfunc	28
11.17.	getvel (gv)	28
11.18.	setvel (sv)	28
11.19.	getnvel (gnv)	29
11.20.	setnvel (snv)	29
11.21.	getsecvel	29
11.22.	setsecvel	29
11.23.	getnsecvel	30
11.24.	setnsecvel	30
11.25.	getaxis	30
11.26.	setaxis	30
12.	Limit Switch Instructions (Hardware and Software)	31
12.1.	getsw	31
12.2.	setsw	31
12.3.	getswst	31

12.4.	getlimit.....	32
12.5.	setlimit.....	32
12.6.	getnlimit.....	32
12.7.	setnlimit.....	32
13.	Calibration and Range Measure Instructions	33
13.1.	calibrate (cal).....	33
13.2.	ncalibrate (ncal).....	33
13.3.	rangemeasure (rm).....	33
13.4.	nrangemeasure (nrm).....	34
13.5.	getcalswdist.....	34
13.6.	setcalswdist.....	34
13.7.	getrmswdist.....	34
13.8.	setrmswdist	34
13.9.	getcalvel.....	35
13.10.	setcalvel	35
13.11.	getrmvel	35
13.12.	setrmvel	35
13.13.	getrefvel	36
13.14.	setrefvel	36
13.15.	getncalvel.....	36
13.16.	setncalvel	36
13.17.	getncaltimeout.....	36
13.18.	setncaltimeout	36
13.19.	getnrmvel	37
13.20.	setnrmvel	37
13.21.	getnrefvel	37
13.22.	setnrefvel	37
13.23.	getcaldone	37
13.24.	setpos (sp)	38
13.25.	setnpos (snp)	38
14.	Move Instructions	39
14.1.	move (m).....	39
14.2.	nmove (nm).....	39
14.3.	rmove (r)	39
14.4.	nrmove (nr).....	40
14.5.	speed	40
14.6.	stopspeed	40
14.7.	randmove	40
14.8.	pos (p).....	41



14.9.	npos (np).....	41
15.	Joystick, Trackball and Handwheel Instructions.....	42
15.1.	getjoystick (gj)	42
15.2.	joystick (j)	42
15.3.	getnjoystick (gnj)	42
15.4.	njoystick (nj)	42
15.5.	getjoyassign	43
15.6.	setjoyassign	43
15.7.	getjoyspeed.....	43
15.8.	setjoyspeed (js)	43
15.9.	getjoybspeed.....	44
15.10.	setjoybspeed	44
15.11.	getjoysticktype.....	44
15.12.	setjoysticktype	44
15.13.	getnjoyspeed	44
15.14.	setnjoyspeed (njs)	44
15.15.	getkey	44
15.16.	getwheelratio	45
15.17.	setwheelratio	45
15.18.	getwheelbratio	45
15.19.	setwheelbratio	45
16.	Digital and Analogue I/O.....	46
16.1.	setdac	46
16.2.	getaout.....	46
16.3.	setaout	46
16.4.	getnout.....	47
16.5.	setnout	47
17.	Encoder and Closed Loop Instructions.....	48
17.1.	getclperiod.....	48
17.2.	setclperiod.....	48
17.3.	getcloop	48
17.4.	setcloop.....	48
17.5.	getclfactor	49
17.6.	setclfactor.....	49
17.7.	getselpos.....	49
17.8.	getnselpos.....	49
17.9.	setselpos.....	49
17.10.	setnselpos	49
17.11.	getencamp	49



17.12.	getenc	50
17.13.	setenc	50
17.14.	getscaleinterface	50
17.15.	setscaleinterface	50
17.16.	getclwindow.....	51
17.17.	setclwindow.....	51
17.18.	getclwintime	51
17.19.	setclwintime.....	51
18.	Trigger Instructions.....	52
18.1.	gettr.....	53
18.2.	settr	53
18.3.	gettrout.....	53
18.4.	settrout	53
18.5.	gettrpol	54
18.6.	settrpol	54
18.7.	gettrlen	54
18.8.	settrlen	54
18.9.	gettrcount	55
18.10.	settrcount	55
18.11.	gettrselpos.....	55
18.12.	settrselpos.....	55
18.13.	gettrdelay	56
18.14.	settrdelay	56
18.15.	gettrf.....	56
18.16.	settrf	56
18.17.	gettrpara.....	57
18.18.	settrpara.....	57
19.	Wait Instructions.....	58
19.1.	waittime (wt)	58
20.	Safety Instructions.....	59
20.1.	abort (a)	59
20.2.	nabort.....	59
20.3.	getinfunc	59
20.4.	setinfunc.....	60
21.	Dummy Instructions.....	61
21.1.	getmotorpara.....	61
21.2.	setmotorpara	61
21.3.	getclpara	61
21.4.	setclpara	61



21.5.	getsp	61
21.6.	setsp	61
22.	Table of Error Numbers	62
23.	Document Revision History	63

2. Introduction

This manual is intended as technical reference for programmers of any software applications using the TANGO controller driven with the so-called Venus command set.

The TANGO controller is configurable for several different command languages. This manual describes the command set for language "Venus for TANGO", which is a superset of both interpreter languages Venus-1 and Venus-2. In general, the fundamental command construction and functions are compatible to these versions.

Examples

<code>cal<CR></code>	calibrate all enabled axes (Venus-1)
<code>2<SP>ncal<CR></code>	calibrate axis 2 only (Venus-2)
<code>status<CR></code>	ask for the status of the controller
<code>1.2<SP>3.4<SP>m<CR></code>	move absolute to x=1.2 and y=3.4 for a 2-axis controller

Please do not send more than 255 characters at once to the TANGO Controller, as the input buffer will overflow. To avoid this, it is recommended to request the status in between and wait for a value to be returned. Another solution is to activate the so called cts-handshake (available with Desktop RS232 and USB versions only). This will automatically halt the PC transmission for as long as the input buffer is full. The PC COM port then must be opened with hardware handshake on, too. Please refer the **getcts** and **setcts** commands for further description. Some of the most common commands are also available in abbreviations, to reduce communication time. Example: The command **setjoyspeed** is available as identical short form **js**.

Secure speed limitation

The TANGO controller has a built-in security function, which reduces the maximum travel velocity to 10mm/s for as long as no initial **cal** and **rm** move is executed. This is to preserve the microscope stage from damage that could be caused by moving fast into its end positions. After calibrating the axis into its both limit switches, the travel velocity is no longer limited.

If this feature does not fit your purpose, the stage speed may be increased to up to 100mm/s at own risk. Please refer to the **getsecvel** and **setsecvel** command for further information.

3. Instruction and Response Syntax Description

All instructions and parameters which are sent to the controller, as well as all feedbacks of the controller, are transferred as a sequence of ASCII characters. The connection can be established e.g. with a terminal program. The use of standard ASCII string communication is easy to understand and simplifies tracing of communication.

The controller does not distinguish between upper- and lower-case ASCII characters. While lower case might be preferred, the controller can also handle upper or camel case strings.

All floating-point numbers may contain a decimal point, commas are not supported.

Each parameter or instruction send to the controller may either be terminated by a carriage return <CR> or a blank <SP>. Both are supported and compatible with existing Venus-1 or Venus-2 installations.

<ETX> is used as special single character instruction, which is processed in a high priority manner. It stops automatic moves immediately at stop deceleration and clears the receive buffer.

Symbol	Name	Decimal	Hexadecimal	Keyboard	Binary
<ETX>	End of Text	3	0x03	Ctrl-C	00000011
<LF>	Line Feed	10	0x0A		00001010
<CR>	Carriage Return	13	0x0D		00001101
<SP>	Space	32	0x20	Blank	00100000

Commands and parameters may be separated or terminated by <SP>, <CR> or both:

command with one parameter	[parameter]<SP>[axis]<SP>[instruction]<CR>
or	[parameter]<SP>[axis]<SP>[instruction]<SP>

The controller response is always terminated with <CR><LF>:

response with one parameter	[parameter]<CR><LF>
response with two parameters	[parameter1]<SP>[parameter2]<CR><LF>

3.1. mode

The instruction **mode** sets the operation mode of the controller.
The TANGO controller only supports host mode (0).

Syntax: mode
Parameter: [0,1] (0 = *host mode* or 1 = *terminal mode*)
Response: none

Examples:
0 mode (set host mode)
1 mode (set terminal mode)

3.2. parameter

Some instructions require no parameter, while other require more than one. The following chapters describe each instruction in detail.

Whenever an instruction requires an [axis] parameter to specify a certain axis, then the legal range is 1 to 4. Some instructions also allow the [axis] set to 0 or -1 for special access.

[axis] = index number	description
1	1st axis (X)
2	2nd axis (Y)
3	3rd axis (Z)
4	4th axis (A)
0	for access to some axis independent parameters
-1	to query all available axes, available with some instructions only

4. Stack Instructions

The Venus interpreter is based on a last in, first out parameter stack. All numbers get pushed on the stack when followed by either a <SP> or <CR>. The instruction finally pops the required amount of parameters off the stack.

Remarks: It is important to know that instructions require a certain amount of parameters and that the amount also might depend on how many axes are available. So if e.g. 3 parameters are provided for an instruction that requires only 2, one parameter remains on the stack. This behavior can be used to have parameters for several instructions already on the stack, and then only call instructions. But the default application, as described in this manual, recommends providing exactly the required amount of command parameters at a time and ensure the stack is empty after its execution.

The stack size is typically 10 parameters. On overflow, no additional parameters get pushed on the stack and an error condition is signalled.

4.1. **gsp**

This instruction returns the number of actual parameters present on stack (stack pointer). After execution of any Venus instructions, the response to this **gsp** instruction should be zero. If this is not the case, this indicates that too many parameters have been sent with the instruction.

4.2. **pop**

This instruction removes the last parameter from the stack. The stack pointer is decremented by one.

4.3. **clear**

This instruction clears the stack and removes all parameters. The stack pointer is set to zero. It can also be used frequently to prevent unused parameters to accumulate on the stack and causing stack overflow and erroneous behavior.

4.4. **nclear**

Same function as the **clear** instruction. Clearing a single axis stack is not supported.

This instruction clears the stack of all axes and removes all parameters. The stack pointer is set to zero.

5. Venus-1 vs. Venus-2 Instructions Cross Reference

The following table contains a cross reference list for Venus-1 and Venus-2 instructions. The TANGO controller provides all these instructions (both command sets can be used at the same time).

In general, the Venus-2 instructions are designed to control a single axis, while the Venus-1 was first designed to control up to three axes simultaneously. Valid short instructions are noted in brackets.

Venus-1	Venus-2	Description
abort or <ETX> [=Ctrl+C, 0x03h]		abort automatic moves
move (m)	nmove (nm)	move absolute
rmove (rm)	nrmove (nrm)	move relative
pos (p)	npos (np)	get position
setpos (sp)	setnpos (snp)	set position
getvel (gv)	getnvel (gnv)	get velocity
setvel (sv)	setnvel (snv)	set velocity
getaccel (ga)	getnaccel (gna)	get acceleration
setaccel (sa)	setnaccel (sna)	set acceleration
calibrate (cal)	ncalibrate (ncal)	calibrate
rangemeasure (rm)	nrangemeasure (nrm)	range measure
getlimit	getnlimit	get limit
setlimit	setnlimit	set limit
getcalvel	getncalvel	get calibration velocity
setcalvel	setncalvel	set calibration velocity
getrmvel	getnrmvel	get range measure velocity
setrmvel	setnrmvel	set range measure velocity
getjoyspeed	getnjoyspeed	get manual speed
setjoyspeed (js)	setnjoyspeed (njs)	set manual speed
version	nversion	get version

For Venus-1 style instructions the parameters depend on the value of **getunit**.
For all Venus-2 style instructions the unit is either [mm] or [mm/s] or [mm/s²].

6. Communication Interface Settings

The TANGO controller family provides several communication interfaces.

The following table shows which interface functions are supported by the different interface types.

	getbaud	setbaud	getcts	setcts
PCI/PCI-E Bus	⊘	⊘	✓	✓
USB	⊘	⊘	✓	✓
RS232	✓	✓	✓	✓
USB (BOB)	✓	✓	⊘	⊘

6.1. getbaud

Syntax: getbaud

Parameter: none

Response: {1200, 2400, 4800, 9600, 19200, 38400, **57600** or 115200}

Default: 57600

This instruction reads the serial communication transfer rate. The unit is bits per second [Bd]. However this instruction only works if the serial connection is already established.

6.2. setbaud

Syntax: [value] setbaud

Parameter: {1200, 2400, 4800, 9600, 19200, 38400, **57600** or 115200}

Response: none

Example: 57600 setbaud

The default baud rate of 57600 may be changed to the requirements of the specific application. However this instruction works only if the serial connection is already established. This instruction changes the baud rate of the controller only. To re-establish communication, the corresponding COM Port of the PC must be opened with the same new baud rate afterwards. Then a **save** instruction may be sent to permanently store the new baud rate in the controller. For PCI, PCI-E and Desktop USB controllers the change of baud rate has no effect, it is always fixed internally to 4,125,000 baud independent of the *setbaud*, *getbaud* parameters.

6.3. getcts

Syntax: getcts

Parameter: none

Response: {0 or 1} (0 = *hardware handshake off*, 1 = *hardware handshake on*)

Default: 0

This instruction reads the current RTS/CTS hardware handshake enable state. The default setting is 0 (off).

6.4. setcts

Syntax: [value] setcts

Parameter: {0 or 1} (0 = *hardware handshake off*, 1 = *hardware handshake on*)

Response: none

Example: 0 setcts

This instruction enables or disables the hardware handshake provided by some TANGO controllers.

0 disables the CTS hardware handshake, which is also the default setting and recommended for most applications. The PC COM Port must be reopened with the same setting. The setting can be stored by save.

7. Controller Informations

The instructions **version**, **nversion**, **identify**, **nidentify** are provided for backward compatibility only. The instructions **getserialno**, **getso**, **tango** report details about hardware and firmware versions.

7.1. version

Syntax: version
Parameter: none
Response: 3.61

7.2. nversion

Syntax: [axis] nversion
Parameter: axis
Response: 3.61
Example: 1 nversion

7.3. identify

Syntax: identify
Parameter: none
Response: Corvus 1 361 1 0

7.4. nidentify

Syntax: [axis] nidentify
Parameter: axis
Response: Pegasus 1 143 0 0
Example: 1 nidentify

7.5. getserialno

Syntax: getserialno
Parameter: none
Response: [YY][WW][V][A][nnn]
Example: 113513017

7.6. getstageno

Syntax: getstageno
Parameter: none
Response: [JJ][MM][TT][nn]
 or [JJ][MM][TT][nnn]
 or ----- if no stage serial number available
Examples: getstageno ==> 110831005
 getstageno ==> -----

7.7. tango

Syntax: tango

Parameter: none

Response: [version string] [CR,LF] [tango serial number]

Syntax: Character string including controller type, firmware version, build date separated by a comma, and the serial number

TANGO	Fixed string identifying the TANGO controller
-DT	Desktop version (PCI based)
-DT-S	Desktop version (PCI-S based)
-DTe	Desktop version (PCIe based)
-PCI	PCI card version (long PCI card)
-PCI-S	Short PCI card version
-PCIe	PCI Express card version
-MINI	TANGO mini
-MINI3	TANGO 3 mini
-C	Motorized Stage with integrated Controller
-I	TANGO integrale stage integrated controller
Version 1.37	Firmware version number
Aug 12 2008	Firmware build date
16:39:01	Firmware build time

Example: TANGO-DTe, Version 1.69, Mar 6 2018 , 15:52:19
143513049

8. System Configuration

Many parameters can be stored permanently in the TANGO Controller, so they are available after each consecutive power on. When stored once, this reduces initialization overhead of the application software. Refer to the "save" instruction for further information.

8.1. save

Syntax: save
Parameter: none
Response: none

This instruction stores your favourite parameter settings (like acceleration and speed) in a permanent and safe data area (also called non-volatile memory). These parameters will be taken by the controller after each consecutive reset or power on as default values.

8.2. restore

Syntax: restore
Parameter: none
Response: none

This instruction overwrites the actual controller setting with parameters read from the non volatile memory.

8.3. reset

Syntax: reset
Parameter: none
Response: none

The controller is forced to perform a software reset. It is a restart similar to power on. Rebooting from reset will take more than 1 second, where the controller is not responding. There is no reply to a software reset. So for knowing if the controller is rebooted and ready, it may be necessary to poll data until it responds again.

8.4. getpowerup

Syntax: getpowerup

Parameter: none

Response: current power up mode

Example: getpowerup (assume response 2 => "calibrate" and "joystick off")

The instruction **getpowerup** reads the current power up mode. The response is a bit combination:

Response		Description
	0	No power up functionality, last saved joystick mode is used
bit 2^0	1	Joystick on after power up or reset
bit 2^1	2	Calibration move after power up or reset
bit 2^2	4** (6)	Range Measure move after power up or reset, ** only to be used together with calibration option: cal+rm = 2+4 = 6
bit 2^3	8	Random move, combination with 2+4 required! (= 14)
bit 2^4	16	Performs Calibration and Range Measure, then travels to the zero position
bit 2^5	32	Enables closed loop after power up or reset

8.5. setpowerup

Syntax: [value] setpowerup

Parameter: required power up mode (refer table above for *getpowerup*)

Response: none

Example: 1 setpowerup (enable joystick after power up)
3 setpowerup (enable joystick and perform calibration after power up)

The instruction **setpowerup** causes the controller to automatically perform the desired behaviour on all active axes after power up or reset. Power up instructions may be combined, but not all combinations are allowed or make sense.

For a complete list of options please refer to the **getpowerup** description.



8.6. getipreter

Syntax: getipreter
Parameter: none
Response: certainly 2 here only

This instruction reads the number of the actual selected interpreter. The response 2 indicates the Venus instruction set is set active as described in this manual.

8.7. setipreter

Syntax: [value] setipreter
Parameter: {1 or 2}
Response: none
Example: 2 setipreter

This instruction selects the required interpreter.

instruction	Description
1 setipreter	switch from Venus to native instruction set (refer separate manual)
!ipreter 2	switch from native to Venus instruction set (see this manual)

9. Motor Configuration

The controller is adaptable for different motors with the following set of instructions.

9.1. **gi**

Syntax: [axis] gi
Parameter: none
Response: motor current in unit Ampere [A]
Example: 2 gi (assume response 0.8 => 0.8 A motor current of axis 2)

This instruction reads the actual motor current in unit Ampere [A].

9.2. **si**

Syntax: [value] [axis] si
Parameter: value is motor current in [A]
Response: none
Example: 0.8 1 si (set motor current 0.8 A for axis 1)

This instruction sets the required motor current. Please read the motor data sheet for details and do not cross the maximum ratings, since this may damage the motor permanently. (This instruction replaces setumotmin and setumotgrad.)

9.3. **getpolepairs**

Syntax: [axis] getpolepairs
Parameter: [axis]
Response: integer
Example: 2 getpolepairs (reads axis 2 number of motor pole pairs)

The instruction **getpolepairs** reads the controller settings for the motor pole pairs of the asked axis.

9.4. **setpolepairs**

Syntax: [value] [axis] setpolepairs
Parameter: value is the number of the motor pole pairs (as an integer number)
Response: none
Example: 50 1 setpolepairs (adapts axis 1 to a motor with 200 steps/rev)

The instruction **setpolepairs** adapts the controller to the required number of motor pole pairs for the requested axis. For clarification: A 2 phase stepper motor with 200 steps/rev has 50 pole pairs.

9.5. **getmotiondir**

Syntax: [axis] getmotiondir
Parameter: [axis] 1,2,3 or 4
Response: 0 = default motor direction
 1 = reversed motor direction
Example: 2 getmotiondir (read axis 2 direction)

The instruction **getmotiondir** reads the motor direction.

9.6. **setmotiondir**

Syntax: [direction] [axis] setmotiondir
Parameter: [axis] 1,2,3 or 4
 [direction] 0 = default motor/axis direction
 1 = reversed motor/axis direction
Response: none
Example: 0 2 setmotiondir (set axis 2 to default direction)

The instruction **setmotiondir** sets the motor direction of the specified axis. The the cal rm assignment is changed automatically.

10. Controller States and Error Messages

The two instructions **geterror** and **getstatus** are useful to determine, if an unusual event has happened or the last instruction was executed. The response to **ge** and **st** reflects the actual controller state.

10.1. geterror (ge)

Syntax: `geterror or ge`
Parameter: `none`
Response: `error code`

The instruction **geterror** reads the current controller error state, which indicates the last occurred error. The error message is deleted after the instruction is executed. Please refer chapter "Table of Error Numbers" for possible values and description.

This instruction can also be used as a blocking instruction in order to wait for completion of a move.

10.2. getnerror (gne)

Syntax: `[axis] getnerror or gne`
Parameter: `axis`
Response: `error code`

The instruction **getnerror** reads the current controller error state, which indicates the last occurred error. The error message is deleted after the instruction is executed. Please refer chapter "Table of Error Numbers" for possible values and description.

This instruction can also be used as a blocking instruction in order to wait for completion of a move.

Implementation is of limited compatibility, no blocking for multiple axes, no error for a single axis available.

10.3. status (st)

Syntax: `status or st`
Parameter: `none`
Response: `actual controller status (integer in range of {0..511})`

The instruction **status** reads the current controller status. The replied value reflects the operating state of the controller in a binary coded decimal representation. To decode the states correctly it is necessary to use a bit mask. Greyed status bits are currently not supported.

Bit	Decimal	0 indicates	1 indicates
D0	1	idle / move completed	controller executes a move
D1	2	manual mode (HDI) is not active	manual mode is active
D2	4	button A not pressed	button A pressed
D3	8	no function	no function
D4	16	speed mode is not active	speed mode is active
D5	32	position out of target window	position within the target window
D6	64	stop signal not active or not enabled	axes stopped by stop signal (setinfunc)
D7	128	motor driver is enabled	motor driver is disabled
D8	256	Joystick button not pressed	Joystick button pressed

10.4. nstatus (nst)

Syntax: nstatus or nst

Parameter: axis

Response: actual axis status (integer in range of {0..255})

Example: 1 nst

The instruction **nstatus** reads the current axis status. The replied value reflects the operating state of the controller axis in a binary coded decimal representation. To decode the states correctly it is necessary to use a bit mask. Greyed status bits are currently not supported.

Bit	Decimal	0 indicates	1 indicates
D0	1	idle / move completed	axis executes a move
D1	2	manual mode (HDI) is not active	manual mode is active
D2	4	no machine error	machine error
D3	8	no function	no function
D4	16	no function	no function
D5	32	position out of target window	position within the target window
D6	64	stop signal not active or not enabled	axes stopped by stop signal (setinfunc)
D7	128	motor driver is enabled	motor driver is disabled

11. General Adjustments

With the following instructions the parameters of the controller are widely scalable to the given mechanic construction and to customer requirements. The controller is adaptable to all the requested requirements.

11.1. **getunit**

Syntax: [axis] getunit
Parameter: axis
Response: integer in range of {0..9}
Example: 2 getunit (read actual unit of axis 2)

The instruction **getunit** reads the unit of all input and output parameters related to length, e.g. position or move instructions. Axis index = 0 (virtual) is used to read the unit of instructions, which influence all axes (like **setvel**, **setaccel**, **setmanaccel**)

The possible values for unit are:

Value	unit
0	Microsteps
1	µm
2	mm
3	cm
4	m
5	inch
6	mil (1/1000 inch)
7	0..360°
8	revolutions
9	mm

We recommend using physical units only. Remember: The unit micro steps is no physical unit, since it is well defined for a certain product only. Nevertheless, the TANGO is configurable to user defined number of micro steps/revolution (refer **getusteps**). There is no need to modify existing applications but only to specify the required number of micro steps (refer **setusteps**).

11.2. **setunit**

Syntax: [value] [axis] setunit
Parameters: value in range of {0..9} (for description see table at *getunit*)
Response: none
Example: 2 1 setunit (set unit [mm] for axis 1)

The instruction **setunit** sets the unit of all input and output parameters related to length, e.g. position or move instructions. Axis index = 0 (virtual) is used here to specify the unit for instructions like **setvel**, **setaccel**, **setmanaccel** which influence all axes.

11.3. **getusteps**

Syntax: `getusteps`
Parameter: `none`
Response: `integer [micro steps/revolution]`
Example: `getusteps (read actual setting of micro steps)`

The instruction **getusteps** reads the actual number of micro steps / revolution. The TANGO default is 819200 micro steps per revolution (for 1.8° motors). In case your application is designed to work with a different value, you may adapt the TANGO to your requirements.

11.4. **setusteps**

Syntax: `[value] setusteps`
Parameters: `value = required microsteps/rev.`
Response: `none`
Example: `40000 setusteps`

The instruction **setusteps** defines the required value for microsteps. The TANGO default is 819200 micro steps per revolution (for 1.8° motors). In case your application is designed to work with a different value, you may adapt the TANGO to your requirements.

11.5. **getdim**

Syntax: `getdim`
Parameter: `none`
Response: `integer in range of {1..4}`
Example: `getdim (read actual setting of value dimension)`

The instruction **getdim** reads the actual setting of dimension of all input and output parameters related to length, e.g. position or move instructions.

The possible values for dimension are:

Value	expected or replied axis parameters
1	[axis1]
2	[axis1] [axis2]
3	[axis1] [axis2] [axis3]
4	[axis1] [axis2] [axis3] [axis4]

11.6. **setdim**

Syntax: `[value] setdim`
Parameters: `value in range of 1 to 4, description see table above`
Response: `none`
Example: `2 setdim (set dimension, the number of used axes, to 2)`

The instruction **setdim** defines how many parameters the controller expects or replies for all dimension dependent instructions only. The instruction **setdim** does not switch on or off any axes.

11.7. getpdisplay

Syntax: [axis] getpdisplay
Parameter: [axis]
Response: [value1] (width of position response)
 [value2] (number of digits after decimal point)
Example: 2 getpdisplay (assume response 9 3 => pos format is "__345.789")

The instruction **getpdisplay** returns the actual position format. The response are two integer numbers. The first is the number of digits including the decimal point. The second is the number of digits after the decimal point.

11.8. setpdisplay

Syntax: [value1] [value2] [axis] setpitch
Parameter: [value1] is the number of all digits
 [value2] is the number of required digits after the decimal point
Response: none
Example: 10 4 1 setpitch (set format f10.4 for **pos** response)

The instruction **setpdisplay** defines the format of the response to instruction **pos**. The first parameter specifies the number of overall required digits including the decimal point. The second parameter specifies the number of digits after the decimal point.

11.9. getpitch

Syntax: [axis] getpitch
Parameter: [axis]
Response: floating point number
Example: 2 getpitch (reads the pitch of axis 2)

The instruction **getpitch** reads the actual setting of pitch of the asked axis.

11.10. setpitch

Syntax: [value] [axis] setpitch
Parameter: value is spindle pitch (as a floating point number)
Response: none
Example: 4.0 1 setpitch (set pitch to 4.0 [mm] for axis 1)

The instruction **setpitch** adapts the controller to the required spindle pitch of the requested axis.

11.11. getaccel (ga)

Syntax: getaccel or ga
Parameter: none
Response: floating point number
Example: ga (reads acceleration (identical value for all axes))

The instruction **getaccel** reads the general acceleration taken for automatic moves. The answer depends on the actual setting of **unit**. Assume the instruction **0 getunit** responds with 2 then the unit of acceleration will be in [mm/s²].

11.12. setaccel (sa)

Syntax: [value] setaccel or sa
Parameter: value is acceleration (as a floating point number)
Response: none
Example: 0.2 sa (sets acceleration to 0.2 (the unit depends on 0 getunit))

The instruction **setaccel** defines the acceleration for automatic moves. It is independent from direction. Any successive move will use this value during calculation. Nevertheless other parameters like e.g. spindle pitch are required to calculate correct. All calculations take care of vectoral move, e.g. the axes will follow a line from start point to end point. They will also reach the destination at the same time.

11.13. getnaccel (gna)

Syntax: [axis] getnaccel or gna
Parameter: axis
Response: floating point number in [mm/s²]
Example: 2 gna (reads acceleration of axis 2)

The instruction **getnaccel** reads the acceleration of the specified axis taken for automatic moves. The unit is in [mm/s²].

11.14. setnaccel (sna)

Syntax: [value] [axis] setnaccel or sna
Parameter: value is acceleration (as a floating point number)
Response: none
Example: 200 2 sna (sets acceleration for axis 2 to 200 [mm/s²])

The instruction **setnaccel** defines the acceleration for the specified axis for automatic moves. It is independent from direction. Any successive move will use this value during calculation. Nevertheless, other parameters like e.g. spindle pitch are required to calculate correct. All calculations take care of vector move, e.g. the axes will follow a line from start point to end point. They will also reach the destination at the same time. When using Venus-2 move instructions, the axes are also able to be positioned independent of each other.

11.15. getnaccelfunc

Syntax: [axis] getnaccelfunc
Parameter: axis
Response: 0 or 1
Example: 2 getnaccelfunc (reads acceleration function of axis 2)

The instruction **getnaccelfunc** reads the selected acceleration function of the specified axis for automatic moves.

11.16. setnaccelfunc

Syntax: [value] [axis] setnaccelfunc
Parameter: 0 = linear accelerations
 1 = sin² acceleration (s-curve)
Response: none
Example: 1 1 sa (sets acceleration for axis 2 to 0.2 [mm/s²])

The instruction **setnaccelfunc** defines the acceleration function for the specified axis for automatic moves.

11.17. getvel (gv)

Syntax: getvel or gv
Parameter: none
Response: floating point number
Example: gv (reads the velocity)

The instruction **getvel** reads the velocity. The answer depends on the actual setting of **unit**. Assume instruction **0 getunit** responds with 2 then the unit of velocity will be in [mm/s].

11.18. setvel (sv)

Syntax: [value] setvel or sv
Parameter: value is the velocity for automatic moves (floating point number)
Response: none
Example: 20 sv (sets the velocity 20, the unit depends on "0 getunit")

The instruction **setvel** defines the velocity for automatic moves. It is independent from direction. Any successive move will use this value. Please make sure the spindle pitch is also set correctly.
The HDI (joystick etc.) velocities must be set using **setjoyspeed** and **setjoybspeed** instructions.

11.19. getnvel (gnv)

Syntax: [axis] getnvel or gnv
Parameter: axis
Response: floating point number in [mm/s]
Example: 2 gnv (reads the velocity of axis 2)

The instruction **getnvel** reads the velocity of the selected axis. The unit is [mm/s].

11.20. setnvel (snv)

Syntax: [value] [axis] setnvel or snv
Parameter: value is the velocity for automatic moves (floating point number)
Response: none
Example: 20 2 snv (sets the velocity 20 mm/s for axis 2)

The instruction **setnvel** defines the velocity for automatic moves for the selected axis. It is independent from direction. Any successive move will use this value. When using Venus-2 nmove instructions, the axes are also able to be positioned independent of each other.

11.21. getsecvel

Syntax: getsecvel
Parameter: none
Response: Currently used secure velocity [1 to 100 mm/s]
Example: getsecvel (read the secure velocity limitation)

The instruction **getsecvel** reads the security speed limitation. This value is used as limit for calculations until the axes are calibrated and range measured (**cal**, **rm**). The velocity unit depends on the **unit** state. It prevents the microscope stage from mechanical damage as long as the controller does not know the mechanical limits.

11.22. setsecvel

Syntax: [value] setsecvel
Parameter: value is the secure speed limitation as floating point
Response: none
Example: 20 setsecvel (limit the axes speed to 20 mm/s)

The instruction **setsecvel** defines the secure speed limitation until **cal** and **rm** are executed. The velocity unit depends on the **unit** state. It prevents the microscope stage from mechanical damage as long as the controller does not know the mechanical limits.

11.23. getnsecvel

Syntax: [axis] getnsecvel
Parameter: axis index is 1,2,3,4 or -1 for all axes (depending on getdim)
Response: Currently used secure velocity of the axis [1 to 100 mm/s] float
Example: 1 getnsecvel (read the secure velocity limitation of the X-axis)

The instruction **getnsecvel** reads the security speed limitation of the specified axis. This value is used as limit for calculations until the axes are calibrated and range measured (**cal**, **rm**). The velocity unit is always mm/s and does not depend on the **unit** state. It prevents the microscope stage from mechanical damage as long as the controller does not know the mechanical limits.

11.24. setnsecvel

Syntax: [value] [axis] setnsecvel
Parameter: value is the secure speed limitation in [mm/s] as floating point
axis index is 1,2,3 or 4
Response: none
Example: 5.5 3 setnsecvel (limit the X-axis speed to 5.5 mm/s)

The instruction **setnsecvel** defines the secure speed limitation until **cal** and **rm** are executed of the specified single axis. The velocity unit is always mm/s and does not depend on the **unit** state. It prevents the microscope stage from mechanical damage as long as the controller does not know the mechanical limits.

11.25. getaxis

Syntax: [axis] getaxis
Parameter: axis index is 1,2,3,4 or -1 for all axes
Response: current state of asked axis
Example: 2 getaxis (read the axis state of axis 2, = Y axis)

The instruction **getaxis** reads the current axis state. The response is either 1, 0 or -1.
Not available axes return -1.

Response	Description
1	enabled
0	disabled (with motor current on)
-1	disabled (with motor current off)

11.26. setaxis

Syntax: [value] [axis] setaxis
Parameter: value is either 1,0 or -1 (refer table above)
Response: none
Example: 1 3 setaxis (enable axis 3)

The instruction **setaxis** enables, disables or switches off the selected axis.

12. Limit Switch Instructions (Hardware and Software)

The instruction set provides hardware limits as well as definable software limits for each axis. Hardware limits protect the axes.

12.1. **getsw**

Syntax: [axis] getsw

Parameter: axis index as usual

Response: [cal switch (E0)] [rm switch (EE)]

Example: 2 getsw (assume response 0 0 => both are normal open)

response	description
0	switch type = normal open
1	switch type = normal close
2	hardware limit switch is ignored

The instruction **getsw** reads the actual settings for the limit switches of the requested axis.

12.2. **setsw**

Syntax: [type] [switch] [axis] setsw

Parameter: [type] see table above and [switch] see table below

Response: none

Example: 2 1 3 setsw (ignore rm switch of axis 3)

[switch]	description
0	cal switch (E0)
1	rm switch (EE)

The instruction **setsw** sets the required type for the hardware limit switches.

12.3. **getswst**

Syntax: [axis] getswst

Parameter: axis index as usual

Response: [cal switch (E0) status] [rm switch (EE) status]

Example: 2 getswst (assume response 0 1 => rm switch of axis 2 is crossed)

The instruction **getswst** reads the actual state of the hardware limit switches.

12.4. getlimit

Syntax: getlimit
Parameter: none
Response: [lower limit] [upper limit]<CR><LF>
 The number of responses depends on **getdim**.
Example: getlimit (read the position limits)
 --> -1000 1000 (assume getdim = 1)
 --> -1000 1000 (assume getdim = 2)
 -1000 1000
 --> -1000 1000 (assume getdim = 3)
 -1000 1000
 -1000 1000

The instruction **getlimit** reads the maximum allowed positioning range. After executing a **cal** and **rm** sequence, the limits are set to the available travel range. They can be narrowed by the **setlimit** instruction. The number of returned values depends on **getdim** (two for each axis). Each pair of lower/upper limits is separated by a <CR><LF>. The unit of the returned values depends on **getunit**.

12.5. setlimit

Syntax: [lower1] [lower2] [lower3] [upper1] [upper2] [upper3] setlimit
Parameter: lower or upper software limit
Response: none
Example: set the limit of all axes to +-1000 (mm)
 -1000 1000 setlimit (assume getdim = 1)
 -1000 -1000 1000 1000 setlimit (assume getdim = 2)
 -1000 -1000 -1000 1000 1000 1000 setlimit (assume getdim = 3)

The instruction **setlimit** sets the maximum allowed positioning range. The number of required parameters depends on **getdim**. There are two parameters for each axis. The parameters must be sent as: first all lower limits, then all upper limits (and not alternating lower/upper). The unit depends on **getunit**.

12.6. getnlimit

Syntax: [axis] getnlimit
Parameter: axis
Response: [lower limit] [upper limit]<CR><LF>
Example: 2 getnlimit (read the allowed positioning range of axis 2 in [mm])

The instruction **getnlimit** reads the maximum allowed positioning range of a single axis. Usually a **ncal** and **nrm** sequence is used to detect both hardware limits. If either only one or no limit switch is mounted, then the response will reflect the user definable software limits instead. The unit depends on **getunit**.

12.7. setnlimit

Syntax: [lower] [upper] [axis] setnlimit
Parameter: lower software limit, upper software limit, axis
Response: none
Example: -1000 1000 2 setnlimit

The instruction **setnlimit** sets the maximum allowed positioning range for one axis. This is useful if either only one or no limit switch is mounted. The unit depends on **getunit**.

13. Calibration and Range Measure Instructions

After each power on or **reset** instruction the actual position of all axes is assumed as zero. Also the travel speed is limited as defined by **getsecvel** until the axes are calibrated and range measured. This prevents mechanical hardware collisions, even if the limit switches are close to the mechanical end.

The user may run a calibration (**cal** or **ncal**) followed by a range measure (**rm** or **nrm**), if the system is equipped with the corresponding limit switches. The cal position becomes the new zero position. The speed during calibration is definable with **setcalvel** and **setrmvel**.

If **getcalswdist** and **getrmswdist** are zero, then the cal and rm position is very close aside the limit switches. All end switch with low hysteresis (e.g. light beam switches and hall effect switches) usually require an extra position offset to prevent unintentional stop at the limits. This offset (e.g. 1mm) is user definable with the instructions **setcalswdist** and **setrmswdist**.

13.1. calibrate (cal)

Syntax: calibrate or cal
Parameter: none
Response: none

This instruction moves all currently enabled axes in negative direction towards lower positions, until the calibration limit switch E0 is detected. It then moves in positive direction out of the switch. If **calswdist**=0, the axis will stop moving as soon as the limit switch E0 is released and set the position to 0.0. If **calswdist**>0, the axes will continue moving until this distance, and then set the position to 0. The final position of each axis is also taken as its lower software limit.

13.2. ncalibrate (ncal)

Syntax: [axis] ncalibrate or ncal
Parameter: axis 1,2,3,4 or -1 to calibrate all active axes
Response: none
Example: 2 ncal (calibrate axis 2)

This instruction moves the selected axis in negative direction towards lower positions, until the limit switch E0 is detected. It then moves it in positive direction out of the switch. If **calswdist**=0, the axis will stop moving as soon as the limit switch E0 is released and set the position to 0. If **calswdist**>0, the axis will continue moving until this distance, and then set the position to 0. The final position is also taken as lower software limit.

13.3. rangemeasure (rm)

Syntax: rangemeasure or rm
Parameter: none
Response: none

This instruction moves all currently enabled axes in positive direction towards higher positions, until the limit switch EE is detected. It then moves in negative direction towards lower positions. If **rmswdist**=0, the axes will stop moving, as soon as the limit switch EE is released. If **rmswdist**>0, the axes will continue moving until this distance. The final position is taken as upper software limit.

13.4. nrangemeasure (nrm)

Syntax: [axis] nrangemeasure or nrm
Parameter: axis 1,2,3,4 or -1 to range measure all active axes
Response: none
Example: 2 nrm (range measure axis 2)

This instruction moves the selected axis in positive direction towards higher positions, until the limit switch EE is detected. It then moves it in negative direction towards lower positions. If rmswdist=0, the axis will stop moving as soon as the limit switch EE is released. If rmswdist>0, the axis will continue moving until this distance. The final position is taken as upper software limit.

13.5. getcalswdist

Syntax: [axis] getcalswdist
Parameter: axis
Response: actual calibration offset
Example: 2 getcalswdist (get cal offset position of axis 2)

This instruction reads the current calibration offset. The unit depends on the current value of instruction **getunit**.

13.6. setcalswdist

Syntax: [value] [axis] setcalswdist
Parameter: value
Response: none
Example: 0.3 2 setcalswdist (set 0.3 cal offset of axis 2)

This instruction specifies an extra offset position above the limit switch E0 (towards higher positions) where to zero the axis and take this position as lower software limit. The unit depends on the current value of instruction **getunit**.

13.7. getrmswdist

Syntax: [axis] getrmswdist
Parameter: axis
Response: actual range measure offset
Example: 2 getrmswdist (get rm offset position of axis 2)

This instruction reads the current range measure offset. The unit depends on the current value of instruction **getunit**.

13.8. setrmswdist

Syntax: [value] [axis] setrmswdist
Parameter: value
Response: none
Example: 0.3 2 setrmswdist (set 0.3 rm offset at axis 2)

This instruction specifies an extra offset position below the limit switch EE (towards lower positions) where to define the upper software limit. The unit depends on the current value of instruction **getunit**.

13.9. getcalvel

Syntax: getcalvel
Parameter: none
Response: value1<CR><LF> value2<CR><LF> floating point numbers in [mm/s]
Example: getcalvel (get cal velocity and cal retract velocity)

This instruction reads the current calibration speeds. Value1 is the speed towards the lower limit switch E0. Value2 is the speed used during retraction from lower limit switch E0. There is only one pair of values for all axes.

13.10. setcalvel

Syntax: [value] [index] setcalvel
Parameter: floating point number in [mm/s] and index
Response: none
Example: 10 1 setcalvel 0.5 2 setcalvel

This instruction defines the required calibration speeds. Index=11 sets the speed towards the lower limit switch E0. Index=2 sets the speed used during retraction from lower limit switch E0. There is only one pair of values for all axes.

13.11. getrmvel

Syntax: getrmvel
Parameter: none
Response: value1<CR><LF> value2<CR><LF> floating point numbers in [mm/s]
Example: getrmvel (get rm velocity and rm retract velocity)

This instruction reads the current range measure speeds. Value1 is the speed towards the upper limit switch EE. Value2 is the speed used during retraction from upper limit switch EE. There is only one pair of values for all axes.

13.12. setrmvel

Syntax: [value] [index] setrmvel
Parameter: floating point number in [mm/s] and index
Response: none
Example: 10 1 setrmvel 0.5 2 setrmvel

This instruction sets the required range measure speeds. Index=1 sets the speed towards the upper limit switch EE. Index=2 sets the speed used during retraction from upper limit switch EE. There is only one pair of values for all axes.

13.13. getrefvel

Syntax: getrmvel
Parameter: none
Response: value<CR><LF> 0.010000<CR><LF> floating point numbers in [mm/s]
Example: getrmvel (get rm velocity and rm retract velocity)

This instruction reads the current range measure speeds. Value1 is the speed towards the reference mark. Value2 is a dummy value.

13.14. setrefvel

Syntax: [value] [index] setrmvel
Parameter: floating point number in [mm/s] and index
Response: none
Example: 10.0 1 setrefvel

This instruction sets the required range measure speeds. Index=1 sets the speed towards the reference mark. Index=2 is unused.

13.15. getncalvel

Syntax: [axis] getncalvel
Parameter: axis
Response: value1<CR><LF> value2<CR><LF> floating point numbers in [mm/s]
Example: 2 getncalvel (get cal velocity and cal retract velocity of axis 2)

This instruction reads the current calibration speeds. Value1 is the speed towards the lower limit switch E0. Value2 is the speed taken during retraction from lower limit switch E0.

13.16. setncalvel

Syntax: [value] [index] [axis] setncalvel
Parameter: floating point number in [mm/s]
Response: none
Example: 10.0 1 3 setncalvel 0.5 2 3 setncalvel (cal velocities of axis 3)

This instruction defines the required calibration speeds. Index=1 sets the speed towards the lower limit switch E0. Index=2 sets the speed taken during retraction from lower limit switch E0.

13.17. getncaltimeout

Syntax: [axis] getncaltimeout
Parameter: axis
Response: value<CR><LF> axis timeout for cal and rm in seconds
Example: 2 getncaltimeout (read timeout of axis 2)
-1 getncaltimeout (read timeout of all axes)

This instruction reads the timeout for cal and rm instructions.

13.18. setncaltimeout

Syntax: [value] [axis] setncaltimeout
Parameter: value in [s], 0 to 120
Response: none
Example: 60 1 setncaltimeout (set timeout of axis 1)

This instruction defines the timeout for cal and rm instructions.

13.19. getnrmvel

Syntax: [axis] getnrmvel
Parameter: axis
Response: value1<CR><LF> value2<CR><LF> floating point numbers in [mm/s]
Example: 2 getnrmvel (get rm velocity and rm retract velocity of axis 2)

This instruction reads the current speeds used during range measurement. Value1 is the speed towards the upper limit switch EE. Value2 is the speed taken during retraction from upper limit switch EE.

13.20. setnrmvel

Syntax: [value] [index] [axis] setnrmvel
Parameter: floating point numbers in [mm/s]
Response: none
Example: 10 1 3 setnrmvel 0.5 2 3 setnrmvel (rm velocities of axis 3)

This instruction sets the required speeds used during range measurement. Index=1 sets the speed towards the upper limit switch EE. Index=2 is the speed taken during retraction from upper limit switch EE.

13.21. getnrefvel

Syntax: [axis] getnrefvel
Parameter: axis
Response: value1<CR><LF> dummy<CR><LF> floating point numbers in [mm/s]
Example: 2 getnrefvel (get reference search velocity of axis 2)

This instruction reads the current calibration speeds. Value1 is the speed towards the reference mark. Value2 is a dummy value of 0.010000.

13.22. setnrefvel

Syntax: [value] [index] [axis] setnrefvel
Parameter: floating point number in [mm/s]
Response: none
Example: 10.0 1 3 setnrefvel (reference search velocity of axis 3)

This instruction defines the required calibration speeds. Index=1 sets the speed towards the reference mark. Index=2 is unused.

13.23. getcaldone

Syntax: [axis] getcaldone
Parameter: axis
Response: cal and rm state of one or all axes as decimal number(s)
Example: 1 getcaldone (query cal and rm executed state of axis 1)
=> 3 returns e.g. a 3 axis 1 = cal+rm already executed
-1 getcaldone (query cal and rm executed state of all axes)
=> 3 3 1 returns 3 for axis 1 and 2 = cal+rm done, 1 for axis3

This instruction reads if a cal or rm instruction was executed on the specified axis.
Return value:

- 1 = no cal or rm executed yet on the axis
- 2 = cal executed (origin set) but no rm yet
- 3 = rm executed but no cal (more or less useless, would only define upper range limit)
- 4 = cal and rm executed on the axis

13.24. setpos (sp)

Syntax: [value1] [value2] [value3] setpos
 or [value1] [value2] [value3] sp
Parameter: origin
Response: none
Example: 0 0 0 setpos (assume dim = 3)

This instruction sets the actual position to the specified value. The number of arguments depends on **getdim** and the unit depends on **getunit**.

Imitation of a bug in Venus-1 instruction set:

If extmode is disabled (which is the default), setpos changes the sign of the position. Because of this, it is recommended to only use setpos to set the positions to zero. Else use **setnpos** as described below.

```
100 10 10 setpos        → pos response -100 -10 -10  
-100 -10 -10 setpos → pos response 100 10 10  
0 0 0 setpos            → pos response 0 0 0
```

13.25. setnpos (snp)

Syntax: [value] [axis] setnpos
 or [value] [axis] snp
Parameter: desired position value, axis 1...4
Response: none
Example: 0 1 setnpos
 15.5 2 setnpos

This instruction sets the actual position of the specified axis. The number of arguments depends on **getdim** and the unit depends on **getunit**.

14. Move Instructions

All move instructions include an automatic linear interpolation. Axes which are started together are reaching the destination at the same time (vector). Axes can also be started independently from each other. In this case each axis drives with its own parameters and may not reach their target positions at the same time.

Blocking instructions are available to generate an automatic position reached reply or execute multiple consecutive moves.

14.1. move (m)

Syntax: [position1] [position2] [position3] move (m)
Parameter: target position
Response: none
Example: 1.23 4.56 7.89 m (dim=3: 3 axis absolute move to 1.23,4.56,7.89)
1.23 4.56 m (dim=2: 2 axis absolute move to 1.23,4.56,7.89)
10 10 m ge (use blocking instruction for completion reply)
10 10 m 0 0 r st (use blocking instruction for completion reply)
1 1 m 0 0 r 5 1 m (use blocking instruction for consecutive moves)

This instruction moves the available axes to the specified absolute position.

The number of required arguments depends on **getdim**.

The unit depends on the value of **getunit**.

14.2. nmove (nm)

Syntax: [value] [axis] nmove (nm)
[value] [mask] nmove (nm)
Parameter: target position of axis or axes
Response: none
Example: Single axis
0.1 2 nm (absolute move axis 2 to 0.1 mm)
100 3 nm (absolute move axis 3 to 100 mm)
Bitmask Synchron move
100 -5 nm (absolute move axis 1 and 3 to 100 mm)
0.2 -3 nm (absolute move axis 1 and 2 to 0.2 mm)

This instruction moves the selected axis or axes to the specified absolute position in [mm].

Positive axis values move a single axis: 1,2,3,4

Combined negative values may be used to move multiple axes: -1, -2, -4, -8,

e.g. -3 moves axis 1 and 2, -6 moves axes 2 and 3

14.3. rmove (r)

Syntax: [distance1] [distance2] [distance3] rmove (r)
Parameter: delta position
Response: none
Example: 0.1 0.2 0.3 rmove (move relative for 3 axes controller: getdim=3)
10 0 r (move relative for 2 axes controller: getdim=2)
0 0 0 r (blocking instruction: wait for all 3 axes
before next instruction is executed)

This instruction moves one or more axes relative to their actual position.

The number of arguments depends on **getdim**.

The unit of the input numbers depends on the current value of **getunit**.

If called with distance 0, it blocks the instruction interpreter as long as the axes are travelling.

14.4. nrmove (nr)

Syntax: [value] [axis] nrmove (nr)
 [value] [mask] nrmove (nr)
Parameter: delta position of axis
Response: none
Example: Single axis
 0.1 2 nrmove (relative move axis 2 by +0.1 mm)
 -10 2 nrmove (relative move axis 2 by -10 mm)
 Bitmask Synchron move
 100 -5 nrmove (relative move axis 1 and 3 by +100 mm)
 0.2 -3 nrmove (relative move axis 1 and 2 by +0.2 mm)

This instruction moves the selected axis or axes relative to their actual position in [mm].
It blocks the instruction interpreter when an addressed axis is still travelling.
Positive axis values move a single axis: 1,2,3,4
Combined negative values may be used to move multiple axes: -1, -2, -4, -8,
e.g. -3 moves axis 1 and 2, -6 moves axes 2 and 3

14.5. speed

Syntax: [speed] [axis] speed
Parameter: speed and axis
Response: none
Example: 0.5 1 speed (X axis travels forward at 0.5 mm/s)
 -10 2 speed (Y axis travels backward at 10 mm/s)
 0 1 speed (stop speed travel of X axis)

This instruction starts a per axis speed move, which travels at the desired speed until stopped.
Speed may be overwritten as desired and will change to the new value with the axis acceleration.
It can be stopped by the **stopspeed** or **abort** instruction or individually by setting the speed to zero.

14.6. stopspeed

Syntax: stopspeed
Parameter: none
Response: none
Example: stopspeed

This instruction stops the speed move off all axes.

14.7. randmove

Syntax: randmove
Parameter: none
Response: none
Example: randmove (starts random move on all active axes)

Randmove starts an endless random move on all active axes.
The position range for random moves can be set by the **setlimit** instruction or by performing a **cal / rm** move.
The velocity varies randomly from 50% to 100% of the selected axis velocity.

14.8. pos (p)

Syntax: pos or p

Parameter: none

Response: Axes positions (depends on state of *getunit*, *getdim*, and *getselpos*)

This instruction reads the current axis positions. The number of values depends on the *getdim* instruction. The unit depends on the *getunit* instruction. The response is either the motor or the encoder position. Please refer *getselpos* and *setselpos* how to select the position source. *Setpos* can be used to set the current positions to a different value.

14.9. npos (np)

Syntax: [axis] npos or np

Parameter: axis 1,2,3 or 4

Response: Axis position (depends on *getselpos*)

This instruction reads the current position of the specified axis. The unit depends on the *getunit* instruction. The response is either the motor or the encoder position. Please refer *getselpos* and *setselpos* how to select the position source. *Setpos* or *setnpos* can be used to set the current positions to a different value.

15. Joystick, Trackball and Handwheel Instructions

The so called HDI interface detects all manual input devices automatically. You are allowed to unplug, plug and exchange these input devices in a safe manner, e.g. the axes keep their position. So called "hot plug" is also provided: You need not to switch off the controller while changing the input devices.

15.1. getjoystick (gj)

Syntax: getjoystick (gj)
Parameter: none
Response: 0=disable, 1=enable
Example: gj => 1 (joystick is enabled)

This instruction reads the manual joystick operation for all axes.

15.2. joystick (j)

Syntax: [parameter] joystick (j)
Parameter: [0,1] 0=disable, 1=enable
Response: none
Example: 1 j (enable joystick operation)

This instruction enables or disables the manual joystick operation for all axes.

15.3. getnjoystick (gnj)

Syntax: [axis] getnjoystick (gnj)
Parameter: axis
Response: 0=disable, 1=enable
Example: 3 gnj => 1 (joystick of axis 3 is enabled)

This instruction reads the manual joystick operation.

15.4. njoystick (nj)

Syntax: [parameter] [axis] njoystick (nj)
Parameter: [0,1] 0=disable, 1=enable
Response: none
Example: 0 2 nj (disable joystick operation for axis 2)

This instruction enables or disables the manual joystick operation for the specified axis.

15.5. getjoyassign

Syntax: [axis] getjoyassign
Parameter: axis
Response: 0,1,2,3,-1,-2,-3
Example: 2 getjoyassign => -2 (joystick direction of axis 2 is inverse)

This instruction reads the manual joystick axis directions.

15.6. setjoyassign

Syntax: [parameter] [axis] setjoyassign
Parameter: 0 = joystick axis disabled
1 = joystick axis assigned to axis 1, default direction
-1 = joystick axis assigned to axis 1, inverse direction
2 = joystick axis assigned to axis 2, default direction
-2 = joystick axis assigned to axis 2, inverse direction
3 = joystick axis assigned to axis 3, default direction
-3 = joystick axis assigned to axis 3, inverse direction
Response: none
Example: 0 3 setjoyassign (disable joystick operation for axis 3)
-2 2 setjoyassign (inverse joystick direction for axis 2)
1 1 setjoyassign (default joystick direction for axis 1)
2 1 setjoyassign (not supported: assigning joy axis 2 to axis 1)

This instruction sets the direction and enables or disables joystick axes. Assigning joystick axes to a different controller axis is currently not supported.

15.7. getjoyspeed

Syntax: getjoyspeed
Parameter: none
Response: actual maximum manual speed (unit as specified with 0 **setunit**)
Example: getjoyspeed (returns maximum manual speed (unit as specified))

This instruction reads the actual maximum manual speed.

15.8. setjoyspeed (js)

Syntax: [parameter] setjoyspeed (js)
Parameter: maximum manual speed (unit as specified with 0 **setunit**)
Response: none
Example: 20 js (set maximum manual speed to 20mm/s (assume 0 **getunit** => 2))

This instruction determines the maximum manual speed. This instruction affects all axes.

15.9. getjoybspeed

Syntax: getjoybspeed
Parameter: none
Response: actual maximum manual speed if button is pressed
Example: getjoybspeed (returns manual speed (unit as specified))

This instruction reads the actual maximum manual speed if button is pressed.

15.10. setjoybspeed

Syntax: [parameter] setjoybspeed
Parameter: maximum manual speed (unit as specified with *0 setunit*)
Response: none
Example: 2 setjoybspeed (set manual speed to 2mm/s (assume *0 getunit* => 2))

This instruction determines the maximum manual speed if button is pressed.

15.11. getjoysticktype

Whenever a HDI device is connected to the controller, it is automatically detected. This instruction is implemented for compatibility purpose only.

15.12. setjoysticktype

Whenever a HDI device is connected to the controller, it is automatically detected. This instruction is implemented for compatibility purpose only.

15.13. getnjoyspeed

Syntax: [axis] getnjoyspeed
Parameter: axis
Response: actual maximum manual speed of requested axis in [mm/s]
Example: 1 getnjoyspeed (responds maximum manual speed of axis 1 in mm/s)

This instruction reads the actual maximum manual speed of a single axis.

15.14. setnjoyspeed (njs)

Syntax: [parameter] [axis] setnjoyspeed (njs)
Parameter: maximum manual speed of requested axis in mm/s
Response: none
Example: 20 2 njs (set maximum manual speed of axis 2 to 20mm/s)

This instruction determines the maximum manual speed of a single axis.

15.15. getkey

Syntax: getkey
Parameter: none
Response: [F1] [F2] [F3] [F4] (0=not pressed or 1 = pressed)
Example: response 1 0 0 1 indicates F1 and F4 were pressed since last query.

This instruction reads, if one or more of the buttons on the joystick panel were pressed since the last getkey instruction. The keys are named F1 to F4.

15.16. getwheelratio

Syntax: [axis] getwheelratio
Parameter: axis 1,2,3
Response: travel distance per handwheel knob revolution in [mm]
Example: 2 getwheelratio (returns distance per rev. of Y axis)

This instruction reads the handwheel travel distance per knob revolution. Also refer to getwheelbratio, which reads the alternate travel distance which can be selected by a button on the device.

15.17. setwheelratio

Syntax: [distance] [axis] setwheelratio
Parameter: axis 1,2,3 and distance in mm
Response: none
Example: 1 14.4 setwheelratio (set X travel distance to 14.4mm/revolution)

This instruction sets, the handwheel travel distance per knob revolution. Also refer to setwheelbratio, which sets the alternate travel distance which can be selected by a button on the device.

The maximum speed of traveling can be limited by the “js” or “njs” instruction.

15.18. getwheelbratio

Syntax: [axis] getwheelbratio
Parameter: axis 1,2,3
Response: travel distance per handwheel knob revolution in [mm]
Example: 1 getwheelbratio (returns distance per rev. of X axis)

This instruction reads the handwheel travel distance per knob revolution. Also refer to getwheelratio, which reads the alternate travel distance which can be selected by a button on the device.

15.19. setwheelbratio

Syntax: [axis] [axis] setwheelbratio
Parameter: axis 1,2,3 and distance in mm
Response: none
Example: 1 1.4 setwheelbratio (set travel distance to 1.4mm/revolution)

This instruction sets, the handwheel travel distance per knob revolution. Also refer to setwheelratio, which sets the alternate travel distance which can be selected by a button on the device.

The maximum speed of traveling can be limited by the “js” or “njs” instruction.

16. Digital and Analogue I/O

The TANGO provides several digital I/O, two analogue outputs (channel 0 and 1) and one analogue input. These are available on the optional auxiliary I/O port.

The analogue output channel 2 is reserved for special purpose. Furthermore, the HDI Interface analogue inputs may be read as well, if no HDI-device is connected.

16.1. setdac

Syntax: [parameter] [channel-ID] setdac
Parameter: [0..100] analogue output in [%] 100% = 10 Volt
Channel-ID: [0..2] channel number
Response: none
Example: 53.2 1 setdac (set channel 1 to 53.2% = 5.32 Volt)

Channel No	Connector	Pin	Signal Name
0	AUX-IO	10	ANOUT0
1	AUX-IO	11	ANOUT1
2	reserved	-	-

This instruction sets the values for analogue outputs in percent. Fractional numbers may be used, too.

16.2. getaout

Syntax: [channel-ID] getaout
Channel-ID: [1 or 2] channel number
Response: [0..10000] analogue output voltage in [mV]
Example: 1 getaout (returns analog output voltage of channel 1 in mV)

Channel No	Connector	Pin	Signal Name
1	AUX-IO	10	ANOUT0
2	AUX-IO	11	ANOUT1

This instruction reads back the values of analogue outputs in millivolts.

16.3. setaout

Syntax: [parameter] [channel-ID] setaout
Parameter: [0..10000] analogue output voltage in [mV]
Channel-ID: [1 or 2] channel number
Response: none
Example: 7500 1 setaout (set channel 1 to 7.5V)

Channel No	Connector	Pin	Signal Name
1	AUX-IO	10	ANOUT0
2	AUX-IO	11	ANOUT1

This instruction sets the analogue output voltages in millivolts.

16.4. getnout

Syntax: [axis] getnout

Response: [integer number 0...15] digital signal level bitmask

Example: 1 getnout (returns an integer value representing the output state)

Bitmask Number	Output Name
1	OUT 0
2	OUT 1
4	OUT 2
8	OUT 3

This instruction reads the current output state of the TANGO I/O1 or Multi I/O extension connector.

The axis parameter must be specified but is not supported (dummy).

Only available with TANGO PCI-E based controllers and TANGO 3 mini.

16.5. setnout

Syntax: [bitmask] [axis] setnout

Parameter: [integer number 0...15] digital signal level bitmask

Response: none

Example: 10 1 setnout (set OUT1 and OUT3 to +24V)

Bitmask Number	Output Name
1	OUT 0
2	OUT 1
4	OUT 2
8	OUT 3

This instruction sets the output state of the TANGO I/O1 or Multi I/O extension connector.

The axis parameter must be specified but is not supported (dummy).

Only available with TANGO PCI-E based controllers and TANGO 3 mini.

17. Encoder and Closed Loop Instructions

The closed loop functionality requires encoder signals as precondition. These signals are automatically validated during each calibration. In case of valid encoder signals the user may use them as feedback for so called closed loop. If the closed loop mode is enabled, the system will use the encoder position as reference. If closed loop mode is disabled, the system will use calculated micro step position as reference.

17.1. getclperiod

Syntax: [axis] getclperiod
Parameter: axis
Response: encoder period in [mm]
Example: 3 getclperiod => 0.02 (indicates 20 µm encoder period for axis 3)

This instruction reads the actual encoder period of the requested axis.

17.2. setclperiod

Syntax: [parameter] [axis] setclperiod
Parameter: [0..1] encoder period in [mm]
Response: none
Example: 0.5 2 setclperiod (set axis 2 encoder period to 0.5 mm)

This instruction defines the actual encoder period for the requested axis.

17.3. getcloop

Syntax: [axis] getcloop
Parameter: axis
Response: status of closed loop (0=OFF and 1=ON)
Example: 1 getcloop => 1 (indicates closed loop is enabled for axis 1)

This instruction reads the actual closed loop state of the requested axis.

A return value of 1 means the closed loop is enabled, but does not indicate an active closed loop:

Closed loop is activated by either a **cal** instruction or after reset/power up, depending on **setpowerup**.

17.4. setcloop

Syntax: [parameter] [axis] setcloop
Parameter: [0..1] 0 = disable or 1 = enable the closed loop
Response: none
Example: 1 2 setcloop (enable closed loop for axis 2)

This instruction enables or disables the closed loop mode for the requested axis.

Closed loop is then activated by either a **cal** instruction or after reset/power up, depending on **setpowerup**.

17.5. getclfactor

Syntax: [axis] getclfactor
Parameter: axis
Response: closed loop factor
Example: 2 getclfactor => 2000 (closed loop factor is 2000 for axis 2)

This instruction reads the closed loop factor of the requested axis.

17.6. setclfactor

Syntax: [parameter] [axis] setclfactor
Parameter: [100..10000] closed loop factor (independent from resolution)
Response: none
Example: 1234 2 setclfactor (set closed loop factor 1234 for axis 2)

This instruction defines the required closed loop factor for the requested axis.

17.7. getselpos

Syntax: [axis] getselpos
Parameter: axis
Response: position source
Example: 1 getselpos => 1 (axis 1 positions are measured encoder positions)

This instruction reads, if the **pos (p)** instruction returns the encoder position (1) or the motor position (0).

17.8. getnselpos

Same as **getselpos**.

17.9. setselpos

Syntax: [parameter] [axis] setselpos
Parameter: [0,1] encoder position reading is 0=disabled 1=enabled
Response: none
Example: 1 2 setselpos (enable axis 2 encoder position reading)

This instruction defines if the **pos (p)** instruction returns the encoder position (1) or the motor position (0).

17.10. setnselpos

Same as **setselpos**.

17.11. getencamp

Syntax: [axis] getencamp
Parameter: axis
-1 reads the amplitude of all axes (parameters depend on dim)
1,2,3 reads the amplitude of axis 1(X) or 2(Y) or 3(Z)
Response: encoder signal amplitude in percent
Example: 3 getencamp => 63 (axis 3 encoder amplitude at 63%)
-1 getencamp => 79 81 63 (all encoder amplitudes when **getdim=3**)

Reads the actual encoder signal amplitude of the specified axis.

17.12. getenc

Syntax: [axis] getenc
Parameter: axis
Response: status of encoder (0=OFF and 1=ON)
Example: 2 getenc => 1 (indicates encoder is enabled for axis 2)

This instruction reads the actual encoder state of the requested axis.
Enabling the encoder manually makes it possible to access the measuring system position by **1 setselpos / pos** without entering the closed loop.

17.13. setenc

Syntax: [parameter] [axis] setenc
Parameter: [0,1] 0 = disable or 1 = enable the encoder
Response: none
Example: 1 2 setenc (enable encoder for axis 2)

This instruction enables or disables the encoder for the requested axis.
Disabling the encoder also disables the closed loop, if active.
Enabling the encoder manually makes it possible to access the measuring system position by **1 setselpos / pos** without entering the closed loop.

17.14. getscaleinterface

Syntax: [axis] getscaleinterface
Parameter: axis 1,2,3
Response: 0 : No encoder interface present
 1 : Quadrature encoder interface (RS422 A/B-TTL)
 2 : 5Vpp MR Analog sin/cos interface **
 3 : 1Vpp Analog sin/cos interface **
Example: 2 getscaleinterface (read interface type of axis 2)

This instruction reads the encoder interface type of the specified axis.
** Older TANGO hardware might only provide a hard-wired 1Vpp or 5Vpp interface.
** Type 3 is supported from Firmware Version 1.60B and higher.

17.15. setscaleinterface

Syntax: [type] [axis] setscaleinterface
Parameter: axis 1,2,3
 type 1 : Quadrature encoder interface (RS422 A/B-TTL)
 2 : 5Vpp MR Analog sin/cos interface **
 3 : 1Vpp Analog sin/cos interface **
Response: none
Example: 1 3 setscaleinterface (interface of axis 3 is Quadrature RS422/TTL)

This instruction sets the encoder interface type of the specified axis.
** Analogue 1Vpp or 5Vpp interpolation capabilities must be configured either by order or activation code.
** Older TANGO hardware (Desktop, PCI, PCI-S, PCI-E) might only support either 1Vpp or 5Vpp MR.

17.16. getclwindow

Syntax: [axis] getclwindow
Parameter: axis
Response: [window in mm] 0 [status] [signal]
 status = 0: status (st,nst) info bit D5 disabled
 = 1: status (st,nst) info bit D5 enabled
 signal : dummy value
Example: 2 getclwindow => 0.0010 0 1 0

This instruction reads the closed loop target window and status settings.

17.17. setclwindow

Syntax: [window in mm] 0 [status] [signal] [axis] setclwindow
Parameter: window = 0.0001 .. 1.0 mm closed loop position window
 status = 0: status, nstatus info bit D5 disabled
 = 1: status, nstatus info bit D5 enabled
 signal : dummy value
Response: none
Example: 0.0001 0 1 0 1 setclwindow
 (ax1 has a 100nm window, D5 status output of in window state)
 0.0020 0 0 0 2 setclwindow
 (ax2 has a 2µm window, no D5 status output)

This instruction defines the closed loop position window and status settings for the requested axis.

17.18. getclwintime

Syntax: [axis] getclwintime
Parameter: axis
Response: [time in seconds]
Example: 1 getclwintime => 0.100

This instruction reads how long the closed loop position must be in the target window.

17.19. setclwintime

Syntax: [time in seconds] [axis] setclwintime
Parameter: axis, time [0 ... 1.000 s]
Response: none
Example: 0.25 1 setclwintime
 (closed loop of axis 1 must remain in the position window for 250 ms)

This instruction defines how long the closed loop position must be in the target window.

18. Trigger Instructions

The TANGO controller can generate either position dependent or periodic signals to trigger external components, e.g. cameras, illumination, laser etc. The trigger function can be assigned to one axis only. TANGO Desktop, PCI-S and PCI-E and TANGO 3 mini controllers can generate up to two trigger signals. The second trigger output may be used to generate a precise delay (refer to `settrout` instruction). When using encoder signals as trigger position source, please make sure that the encoders are enabled and activated by the TANGO before executing `settrpara`. Usually encoders are activated after executing the `calibrate` instruction.

The trigger instructions are:

- **`settr`** sets the trigger mode (to disabled, enabled as position dependent or periodic)
- **`settrout`** selects the trigger output(s) 1, 2 or 1+2
- **`settrpol`** selects the output signal polarity (active high or low)
- **`settrlen`** set the output signal length (pulse width)
- **`settrcount`** a counter that counts the generated trigger pulses, read by `gettrcount`
- **`settrselpos`** selects the position source (motor position or encoder position)
- **`settrdelay`** optional time delay for 2nd trigger output compared to 1st output
- **`settrf`** set the free running trigger frequency in trigger mode 2 (refer to `settr`)
- **`settrpara`** sets and enables the position dependent trigger (positions, number of pulses)

Trigger example:

```

0 1 settr           disable the trigger (here: for axis 1/X)
0 2 settr           disable the trigger (here: for axis 2/Y)
0 3 settr           disable the trigger (here: for axis 3/Z)
1 settrout          select trigger output      (e.g. here: output 1)
1 settrpol          set trigger polarity      (e.g. here: active high)
0.04 settrlen       set trigger pulse width  (e.g. here: 40µs)
1 settrselpos       set trigger source       (e.g. here: encoder)
--> initialization is complete, now move and trigger
9 20 5 m            move to start position   (slightly before 1st trigger)
1 1 settr           assign trigger to axis   (here: X axis)
10 20 11 1 settrpara set and enable X trigger (here: 11x - at 10,11, ...20)
0 settrcount        option in case the generated triggers should be checked
21 20 5 m           move to end position    (slightly past final trigger)
gettrcount          ==> 11                  (optional counter read)
...

```

Remarks:

1) It is good practice to use `ge` (read back the `get` error instruction) after each `set` instruction in order to detect errors and to avoid receive buffer overflow.

2) The end of a move can be checked in different ways, this example doesn't take care of it.

18.1. gettr

Syntax: [axis] gettr
Parameter: axis
Response: trigger mode for specified axis
0 = Trigger disabled
1 = Scan-Trigger (positions)
2 = Free running trigger (periodic signal)
Example: 1 gettr => 0 (trigger for axis 1 is disabled)

This instruction reads the trigger mode of the specified axis. Only one axis can be active at a time.

18.2. settr

Syntax: [trigger mode] [axis] settr
Parameter: trigger mode: 0 = Trigger disabled
1 = Scan-Trigger (positions)
2 = Free running trigger (periodic signal)
axis
Response: none
Example: 2 1 settr (set trigger mode to permanent frequency output)

This instruction sets the trigger mode for the specified axis. Only one axis can be active at a time.

18.3. gettrout

Syntax: gettrout
Parameter: none
Response: trigger output mode
Example: 1 gettrout => 11
(both trigger outputs are used, output 2 is in precise delay mode)
1 gettrout => 1
(default trigger output mode on most TANGO controllers)

This instruction reads the trigger output mode. For a table of trigger modes, please refer to **settrout**.

18.4. settrout

Syntax: [trigger output mode] settrout
Parameter: trigger output modes:

AUX-I/O Output	STANDARD	PREC.WIDTH2	PREC.DELAY2	PREC.FREQUENCY2
[no]	0	(4)	(8)	(12)
TRIGGER_OUT	1	(5)	(9)	(13)
TAKT_OUT	2	6	10	14
TRIGGER+TAKT	3	7	11 **	15

** required for precise delay of secondary trigger output

Response: none
Example: 1 settrout (default mode for TANGO controllers)
3 settrout (secondary trigger output does the same as main trigger)
11 settrout (secondary trigger signal after trdelay time)

This instruction defines the trigger output mode. Modes 4..7 and 12..15 are currently not available.

18.5. gettrpol

Syntax: gettrpol
Parameter: none
Response: trigger polarity
 0 = falling edge, active low
 1 = rising edge, active high (default)
Example: gettrpol => 1

This instruction reads the trigger output polarity.

18.6. settrpol

Syntax: [polarity] settrpol
Parameter: 0 = falling edge, active low
 1 = rising edge, active high (default)
Response: none
Example: 1 settrpol (set trigger polarity to active high)

This instruction defines the trigger output polarity.

18.7. gettrlen

Syntax: gettrlen
Parameter: none
Response: trigger pulse length in Milliseconds [ms]
 0.000 ~ 25000.000
Example: gettrlen => 0.040 (trigger pulse length is 40µs)

This instruction reads the trigger output signal length.

18.8. settrlen

Syntax: [trigger pulse length] settrlen
Parameter: 0.00 ~ 25000 (in 0.04 ms steps)
Response: none
Example: 0.04 settrlen (set trigger pulse length to 40µs)
 10 settrlen (set trigger pulse length to 10ms)
 0 settrlen (set pulse to shortest possible length)

This instruction defines the trigger output signal length in milliseconds.

18.9. gettrcount

Syntax: `gettrcount`

Parameter: none

Response: Number of generated trigger events
(since trigger enabled or resetted)

Example: `gettrcount => 100` (100 trigger pulses have been generated)

This instruction reads the trigger event counter.

18.10. setttrcount

Syntax: `[count] setttrcount`

Parameter: new trigger counter value, typically 0
0 ~ 2147483647

Response: none

Example: `0 setttrcount` (reset trigger counter)

This instruction sets the trigger event counter to the specified count.

18.11. gettrselpos

Syntax: `gettrselpos`

Parameter: none

Response: Trigger source:
0 = Motor position
1 = Encoder position

Example: `gettrselpos => 0` (trigger uses internal motor position)

This instruction reads the trigger position source.

18.12. setttrselpos

Syntax: `[position source] setttrselpos`

Parameter: Trigger source: 0 = Motor position
1 = Encoder position (only with analogue encoders)

Response: none

Example: `1 setttrselpos` (trigger uses encoder position)

This instruction defines the trigger position source.

Remarks: When using encoder position (1), please ensure that the encoders are enabled and activated before executing `settrpara`. Else the TANGO will use the motor position even if `trselpos` is set to 1.

Usually encoders are activated after executing the `calibrate` instruction.

Encoder position dependent trigger is only available with analogue sin/cos encoders. In case of A/B TTL encoders, the trigger source 0 (motor position) must be used.

18.13. gettrdelay

Syntax: [axis**] gettrdelay
Parameter: axis
Response: trigger signal delay for secondary trigger output in [μ s]
Example: 1 gettrdelay => 1.5 (trigger delay is 1.5 μ s)

This instruction reads the delay of the secondary trigger signal.

** The axis parameter must be used for compatibility but is ignored internally (one delay applies to all axes).

18.14. settrdelay

Syntax: [delay] [axis**] settrdelay
Parameter: [0.0 .. 32500000.0]
Response: trigger signal delay for secondary trigger output in [μ s]
Response: none
Example: 10.5 1 settrdelay (set trigger signal delay to 10.5 μ s)

This instruction defines the delay of the secondary trigger signal, which is used when settrout option 11 is set. This function is only available with TANGO PCI-E based controllers and TANGO 3 mini.

** The axis parameter must be used for compatibility but is ignored internally (same delay for all axes).

18.15. gettrf

Syntax: [axis**] gettrf
Parameter: axis
Response: trigger frequency in [Hz]
Example: 1 gettrf => 10.000 (trigger frequency is 10 Hz)

This instruction reads the trigger frequency of periodic signal (for settr mode 2).

** The axis parameter must be used for compatibility but is ignored internally (one delay applies to all axes).

18.16. settrf

Syntax: [frequency] [axis**] settrf
Parameter: [0.010 .. 12500.000]
Response: trigger frequency in [Hz]
Response: none
Example: 1000 1 settrf (set trigger frequency to 1kHz)

This instruction defines the trigger frequency of periodic signal (for settr mode 2).

** The axis parameter must be used for compatibility but is ignored internally (same delay for all axes).

18.17. gettrpara

Syntax: [axis] gettrpara
Parameter: axis
Response: [startpos] [endpos] [count]
 trigger parameter for specified axis
Example: 1 gettrpara => 10.0000 90.0000 5
 (5 equidistant trigger points from 10 to 90 mm: 10, 30, 50, ...)

This instruction reads the trigger position settings (for settr mode 1).

18.18. settrpara

Syntax: [startpos] [endpos] [count] [axis] settrpara
Parameter: startpos = position where first trigger is generated
 endpos = position where last trigger is generated
 count = number of equidistant trigger points **
 axis = which axis to be used
Response: none
Example: 10 110 11 1 settrpara (11 trigger positions in X from 10 to 110 mm)

 110 10 11 1 settrpara (same, but in reverse direction)

 5.553 7.553 21 2 settrpara
 (21 trigger positions in Y, trigger distance is 0.1µm)

 100 100 1 1 settrpara (one trigger at 100 mm)
 (The trigger direction then depends on the axis position)

This instruction defines equidistant trigger positions from a start- to an endpoint (when in settr mode 1).

The trigger direction is unidirectional.

The axis position must be in front of the trigger start position in order to charge the trigger.

As long as the settr mode 1 is not changed, the trigger will recharge after returning to a position in front of the trigger start position.

Also, the last trigger will be generated when passing the last trigger position, meaning the move must go slightly farther than the last trigger position.

If only one trigger must be generated, the axis position at which the settrpara or settr instruction was executed determines the trigger direction (pos < triggerpos → positive, pos > triggerpos → negative).

Remarks:

In general, it is good practice to allow the axis to accelerate to its constant velocity before reaching the first trigger position and begin deceleration after the last trigger. This will deliver the best possible results, at least when triggering in open loop applications without a measuring system.

As the first trigger is released at the start position, please consider that e.g. triggering from position 10 to 20 requires 11 counts to achieve a 1mm trigger distance.

** The number of trigger points is limited. Depending on the firmware and controller type a maximum of 2047, 8191 or 10000 triggers is possible. If more than the available trigger positions are specified, settrpara will generate an error.

19. Wait Instructions

19.1. waittime (wt)

Syntax: [time] [unit] wt

Parameter: time,

unit: 0 = ticks of 0.25ms (time = 1 ... 65000 ticks = 16.25s)
1 = seconds (time = 0.001 ... 240 s)

Response: --

Example: 1 1 waittime (wait one second)
2.5 1 wt (wait 2.5 seconds)
2 0 wt (wait 0.5 milliseconds)

This instruction prevents execution of the following instructions for the specified time.
Two units are available: ticks (in 0.25ms) and seconds (resolution down to 1ms).

20. Safety Instructions

20.1. abort (a)

Syntax: abort
 or a
 or Ctrl+C (0x03 hex)
Parameter: none
Response: none
Example: a

This instruction stops all axes. May not work with blocking instructions.
In such case it is recommended to send the abort character "Ctrl-C" (hex 0x03), which works independent of the instruction interpreter and also aborts blocking instructions.

20.2. nabort

Syntax: [axis] nabort
Parameter: axis 1,2,3 or 4
Response: none
Example: 2 nabort

This instruction stops individual axes. May not work with blocking instructions.
In such case it is recommended to send the abort character "Ctrl-C" (hex 0x03), which also aborts blocking instructions but stops all axes.

20.3. getinfunc

Syntax: [input] [axis] getinfunc
Parameter: input = Digital input to which the functionality is assigned
 axis = Axis to which the functionality is assigned
Response: current functionality of the selected input (refer to setinfunc)
Example: 1 3 getinfunc ==> 3 (digital input #1 of Z-axis has functionality 3)

This instruction reads the stop signal configuration.

20.4. setinfunc

Syntax: [function] [input] [axis] setinfunc
[function] 0 0 setinfunc ***

Parameter: *** The TANGO AUX-I/O stop input is addressed by sending axis and input as 0 (zeros). It is always assigned to all axes.

input = Digital input to which the functionality is assigned
axis = Axis to which the functionality is assigned
function =

-1 = clears a latched (sticky) stop condition

0 = Stop function disabled
1 = not available
2 = not available
3 = not available

20 = stoppol 0 active low \ stopped as long as signal applied
21 = stoppol 1 active high / joystick operation remains enabled

22 = stoppol 2 active low \ stopped as long as signal applied
23 = stoppol 3 active high / joystick operation disabled

24 = stoppol 4 active low \ stop latched until "-1 0 0 setinfunc"
25 = stoppol 5 active high / joystick operation disabled

28 = like 20, waits until any active move has completed
29 = like 21, waits until any active move has completed

30 = like 22, waits until any active move has completed
31 = like 23, waits until any active move has completed

32 = like 24, waits until any active move has completed
33 = like 25, waits until any active move has completed

Response: --

Example: 0 5 2 setinfunc (disable stop function of Y-axis digital input #5)
21 0 0 setinfunc (TANGO: set the stop input to stoppol 1 mode)
-1 0 0 setinfunc (TANGO: clear a latched stop condition)

This instruction configures the stop signal functionality of the specified digital input and axis.

21. Dummy Instructions

Dummy instructions are implemented for compatibility only. They do not affect the controller's behaviour.

21.1. getmotorpara

Syntax: [index] [axis] getmotorpara
Parameter: index 1,2 or 3
axis 1,2,3 or 4
Response: index=3: [I²t limit] [current I²t value] as integer
Example: 3 1 getmotorpara (returns X-axis values, e.g. 40000 92)
2 1 getmotorpara (returns X-axis values, e.g. 0.000000 0)

21.2. setmotorpara

Syntax: [value] 3 [axis] setmotorpara
Parameter: maximum I²t value
axis index 1,2,3 or 4
Response: --
Example: 40000 3 1 setmotorpara (set X-axis I²t limit to 40000)

21.3. getclpara

Syntax: [axis] getclpara
Parameter: axis index 1,2,3 or 4
Response: [P] [I] [D] as floating point numbers
Example: 1 getclpara (returns 0 2 0.15)

21.4. setclpara

Syntax: [P] [I] [D] [16383] [SP5] [SP6] [dpos] [ivel] [cutoff] [SP10] [np] [axis] setclpara
Parameter: Closed loop parameter or subset of parameter defined by [np]
np is 1 to 10, depending on the number of parameters sent
axis index 1,2,3 or 4
Response: --
Example: 0 5.3 0.001 3 1 setclpara (only set PID parameters of X-axis)

21.5. getsp

Syntax: [SP index] [axis] getsp
Parameter: SP Parameter index 1 to 10 as integer,
axis 1,2 or 3
Response: Specified parameter as float or integer, depending on parameter
Example: 2 1 getsp (returns closed loop parameter 2 = I param. for X-axis)

21.6. setsp

Syntax: [value] [SP index] [axis] setsp
Parameter: value as float or integer, depending on indexed parameter
SP Parameter index 1 to 10 as integer,
axis 1,2,3 or 4
Response: --
Example: 0.15 3 2 setsp (set closed loop D parameter of Y-axis to 0.15)

22. Table of Error Numbers

The response to instruction **geterror (ge)** is an error number. The following table contains a description of these error numbers and a description of the possible root cause.

Error Number	Description
0	no error
1001	wrong parameter type
1002	not enough parameters on the stack for the instruction
1003	invalid parameter
1004	move stopped working range should run over
1007	invalid parameter value
1008	stack is empty (or contains not enough parameters)
1009	stack is full
1015	parameter outside allowed limits
1020	arc tan
1027	
1029	
1100	division through zero
1200	non-volatile memory write error
1234	error during calibration
2000	unknown instruction

Please refer instruction **geterror (ge)** for further details.

23. Document Revision History

No.	Revision	Date	Changes	Remarks
01		17. June 2008		birthday
	A	23. February 2010	Description corrected: setcalvel, setrmvel, setncalvel, setrmvel Added instructions: setrefvel, getrefvel, setnrefvel, getnrefvel	Firmware 1.51
	B	07. April 2010	Extended description of geterror	
	C	20. July 2010	New MW Logo	
	D	22. July 2010	Added instructions: getwheelratio, setwheelratio, getwheelbratio, setwheelbratio,	Firmware 1.521
	E	29. July 2010	Description of status (st) corrected, Added instructions nstatus (nst), setclwindow, getclwindow, setclwintime, getclwintime, getnaccelfunc, setnaccelfunc, nclear, getjoystick (gj), njoystick (nj), getnjoystick (gnj), getnerror (gne)	Firmware 1.522
	F	26. August 2010	Added instructions getaout, setaout, changed document title from "MST Dokument" to "TANGO Instruction Set Venus"	Firmware 1.528
	G	07. October 2010	Added trigger instructions: gettr, settr, gettrout, settrout, gettrselpo, settrselpo, gettrdelay, settrdelay, settrf, gettrf, gettrpara, settrpara	Firmware 1.534
	H	28. October 2010	setpowerup example corrected, getpowerup description nmove, nrmove with bitmask, extended powerup, randmove	Firmware 1.543
	I	01. December 2010	Added instructions: getjoyassign, setjoyassign, tango	Firmware 1.561
	J	10. February 2011	Improved description of trigger functionality	
	K	15. February 2011	gettrpol, settrpol, gettrlen, settrlen, gettrcount, settrcount	Firmware 1.5682
	L	17. February 2011	Added waittime (wt), improved description of move	Firmware 1.5691
		04. March 2011	Added speed, stopspeed, nabort, improved abort description	Firmware 1.56
	M	08. March 2011	Added setenc, getenc	Firmware 1.57
			Added getencamp	Firmware 1.57
		10. March 2011	Added getscaleinterface, setscaleinterface	Firmware 1.57
		12. August 2011	Added getnsecvel, setnsecvel, Added dummy instructions: getmotorpara, setmotorpara, getclpara, setclpara, getsp, setsp	Firmware 1.57
		01. Sept. 2011	Added getinfunc, setinfunc, getstageno getserialno now reports TANGO S/N	Firmware 1.57
		11. October 2011	Added getmotiondir, setmotiondir	Firmware 1.57
		14. December 2011	Added setnout, getnout	Firmware 1.57
		20. July 2012	Changed setnout, getnout description to I/O1	Firmware 1.57
		07. Sept. 2012	Naming conventions	Firmware 1.57
		26. October 2012	Improved settrpara description Added setncaltimeout, getncaltimeout Corrected description of setdim	Firmware 1.59
	N	18. February 2013	Document released for TANGO Firmware 1.60	Firmware 1.60
		22. October 2013	New functionality of getaxis instruction: Returns -1 if no axis Unified, consistent use of the term "instruction"	Firmware 1.62
		25. June 2015	Modified stack description	
		21. October 2015	Added instructions, improved descriptions, extended trigger descriptions and settrpara	Firmware 1.66
	O	10. November 2015	Improved command set explanation, introduction Document released for TANGO Firmware 1.66	Firmware 1.66



		04. July 2018	Added getcaldone instruction	Firmware 1.70
	P	01. August 2018	Release for TANGO Firmware versions 1.70 / 1.60S5	Firmware 1.70
		13. January 2020	Correced setlim parameter description first all lower limits, then all upper, not alternating lower/upper	Firmware 1.72B
	Q	24. February 2020	Document type changed from .odt to .docx	